

ADA DOOR CONVERSION INSTRUCTIONS

ITEM NUMBERS

C-ADA-OP
ADA Open Nylon Cord & Handle
C-ADA-CL
ADA Close Nylon Cord & Handle

REQUIRED TOOLS

cordless drill
1/4" drill bit



C-ADA-OP (Open Handle)

1. Make sure door is closed.
2. Mark location of drill holes:
 - Approximately 10" from edge of door latch and 24" from floor (bottom of installed handle to hang no lower than 15" from floor)
 - Mark 2 holes side by side and 1-1/8" apart on a high rib of the door
 - Drill 2 holes with 1/4" drill bit
3. Feed one end of black rope through a drilled hole and the other black rope through the remaining hole.
4. Open door, go inside unit and tie a square knot with the ends of the black rope.

C-ADA-CL (Close Handle)

1. Open door and enter unit. Keep bottom of door positioned within reach.
2. Thread the black rope end of the handle into the plate frame through the available hole at the bottom of the door. Tie a square knot with the ends of the black rope.
3. When the door is open, the loop handle should not hang lower than 40" to 48" off the floor.



PLEASE NOTE:

A fitted ramp may be necessary for units without wheelchair access.