


ASCENT

Wiegand Device to Ascent 30-511 Circuit Board

Wiegand Device

Ascent



A CAUTION!

Disconnect power to Ascent unit before connecting Wiegand devices.

Failure to disconnect power can damage unit!

(!) IMPORTANT!

Wiegand inputs are **NOT AVAILABLE** on all Ascent models.

Please ensure your model is Wiegand compatible before proceeding.

NEED HELP

Call **(844) 259-8265**

Email support@summitcontrol.com

We are available Mon-Fri / 8am-5pm Central



© 2018 Security Brands, Inc. All rights reserved. WG-\