

## **Open, Close & Stop Transmitter to Control 9 Doors.**Match dipswitches 1 thru 6 on both transmitter and receiver. Set the 7th and 8th dipswitch in open/close/stop receivers accordingly.

Receiver	Dial Setting	7th Dipswitch on Receiver	8th dipswitch on Receiver
Door 1			
Door 2	2		"O"
Door 3	3		
Door 4	4	"O"	«نب <sup>۲</sup> ۶۶
Door 5	5	"O"	"O"
Door 6	6	"O"	\$ 2.5 ************************************
Door 7	7		**4
Door 8	8		"O"
Door 9			

<sup>&</sup>quot;Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment"