
535T



Open, Close & Stop Transmitter to Control 27 Doors. Match dipswitches 1 thru 5 on both transmitter and receiver. Set the 6th, 7th, & 8th dipswitch in open/close/stop receiver accordingly.

"Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment"

| Receiver | Dial Setting 1-9 | Dial Setting ABC | 6th Dipswitch on Receiver | 7th Dipswitch on Receiver | 8th dipswitch on Receiver |
|----------|---------------------|---------------------|------------------------------|------------------------------|------------------------------|
| Door 1 | 1 | A | 44" | "+" | "+" |
| Door 2 | 2 | A | 4," | "+" | "0" |
| Door 3 | 3 | A | 44.99 | "+" | и |
| Door 4 | 4 | A | 44" | "O" | "+" |
| Door 5 | 5 | A | "+" | "0" | "0" |
| Door 6 | 6 | A | "+" | "O" | 11_39 |
| Door 7 | 7 | A | "+" | 1377 | "+" |
| Door 8 | 8 | A | "+" | "_" | "O" |
| Door 9 | 9 | A | "+" | 4497 | 11_21 |
| Door 10 | 1 | В | "O" | "+" | "+" |
| Door 11 | 2 | В | "O" | "+" | "O" |
| Door 12 | 3 | В | "O" | "+" | - "" |
| Door 13 | 4 | В | "O" | "O" | "+" |
| Door 14 | 5 | В | "O" | "O" | "O" |
| Door 15 | 6 | В | "O" | "O" | 66 |
| Door 16 | 7 | В | "O" | ٠٤ | "+" |
| Door 17 | 8 | В | "O" | ٠٤ | "O" |
| Door 18 | 9 | В | "O" | · · _ · · · | ٠٠ |
| Door 19 | 1 | С | | "+" | 44_44 |
| Door 20 | 2 | С | 4_11 | "+" | "O" |
| Door 21 | 3 | C | "_" | "+" | "" |
| Door 22 | 4 | C | 11_11 | "O" | 16+29 |
| Door 23 | 5 | C | u_n | "0" | "0" |
| Door 24 | 6 | C | 4_77 | "O" | 14 |
| Door 25 | 7 | C | 11. | 1479 | "+" |
| Door 26 | 8 | C | 14_19 | 1699 | "0" |
| Door 27 | 9 | С | 4 | 4527 | 14_39 |