



Wayne-Dalton Corp.
P.O. Box 67 Mt. Hope, OH 44660
(888) 827-3667
www.wayne-dalton.com

2-Button Wired Wall Station

for Classicdrive®, Prodrive™ and Quantum® Openers
Installation Instructions
Model: 3976

Locate wall station at a minimum height of 5 ft., and at least 5 ft. away from garage door.

⚠ WARNING: INSTALL ALL WALL STATION(S) OUT OF THE REACH OF CHILDREN AND IN A LOCATION WHERE THE DOOR CAN BE KEPT IN FULL VIEW WHILE OPERATING. DO NOT MOUNT WALL CONTROLS NEAR OR NEXT TO GARAGE DOOR, TO AVOID POSSIBLE CONTACT WITH MOVING DOOR.

⚠ WARNING: TO PREVENT UNINTENDED OPERATION OF THE OPENER, DISCONNECT 120 VAC ELECTRICAL POWER SUPPLY TO OPENER.

Wired Wall Station: Wire the garage door opener wall station to the opener, using bell wire (low voltage electrical wire) provided. Connect bell wire to COM and P.B. terminals on both the wall station and door opener.


CAUTION: OVER TIGHTENING THE SCREWS COULD DEFORM PLASTIC.

Pilot drill mounting holes using a 3/32" bit and fasten the wall station in a safe location with the (2) Phillips head screws, making sure not to over tighten the screws.

Additional wired wall stations may also be installed in accordance with these instructions.

Reconnect 120 VAC electrical power to the opener. Test operation of the wall station up/down and lamp buttons, in accordance with the instructions included with the opener. Consult your opener manual for important safety information.

IMPORTANT: CONNECT THE LOW VOLTAGE WIRE TO THE WALL STATIONS USING A "J" HOOK CONFIGURATION. IF WIRE IS COMPLETELY LOOPED AROUND TERMINAL SCREW, IT CAN PREVENT PROPER CONTACT.



2 - Button Wired Wall Station

Model No. 3976

ONE YEAR LIMITED WARRANTY

Wayne-Dalton Corp. (The Manufacturer) warrants the 2-BUTTON WIRED WALL STATION will be free from defects in materials and workmanship for a period of ONE YEAR from the date of installation, provided it is properly maintained and cared for under normal use and service.

This Warranty extends to the original homeowner, providing the 2-BUTTON WIRED WALL STATION is installed in his/her place of primary residence. It is not transferable. The warranty applies to residential property only and is not valid on commercial or rental property.

NO EMPLOYEE, DISTRIBUTOR, OR REPRESENTATIVE IS AUTHORIZED TO CHANGE THE FOREGOING WARRANTIES IN ANY WAY OR GRANT ANY OTHER WARRANTY ON BEHALF OF MANUFACTURER.

The Manufacturer shall not be responsible for any damage resulting to or caused by its products by reason of installation; improper storage, unauthorized service, alteration of products, neglect or abuse, any acts of nature beyond Manufacturer's control (such as, but not limited to, lightning, power surges, water damage, etc.), or attempt to use the products for other than the customary usage or for their intended purposes. The above warranty does not cover normal wear or any damage beyond Manufacturer's control or replacement labor.

THIS WARRANTY COVERS A CONSUMER PRODUCT AS DEFINED BY THE MAGNUSON-MOSS WARRANTY ACT. NO WARRANTIES, EXPRESSED OR IMPLIED, (INCLUDING, BUT NOT LIMITED TO, THE WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), SHALL EXTEND BEYOND THE APPLICABLE TIME PERIOD STATED IN BOLD FACE TYPE ABOVE.

Claims for defects in material and workmanship covered by this warranty shall be made in writing, within the warranty period, to the dealer from whom the product was purchased. Manufacturer may either send a service representative or have the product returned to the Manufacturer at Buyer's expense for inspection. If judged by Manufacturer to be defective in material or workmanship, the product will be replaced or repaired at the option of the Manufacturer, free from all charges except authorized transportation and replacement labor.

THE REMEDIES OF BUYER SET FORTH HEREIN ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER REMEDIES, THE LIABILITY OF MANUFACTURER, WHETHER IN CONTRACT, TORT, UNDER ANY WARRANTY OR OTHERWISE, SHALL NOT EXTEND BEYOND ITS OBLIGATION TO REPAIR OR REPLACE. AT ITS OPTION, ANY PRODUCT OR PART FOUND BY MANUFACTURER TO BE DEFECTIVE IN MATERIAL OR WORK SHALL NOT BE RESPONSIBLE FOR ANY DIRECT, INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE.

This Warranty gives you specific legal rights, and you may have other rights, which may vary from state to state. However, some states do not allow limitation on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages so the above limitations or exclusions may not apply to you.

FCC and IC Statement

FCC Regulatory Information:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IC Regulatory Information:

This Class B digital apparatus meets all requirements of the Canadian Interference Causing Equipment Regulations. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide

reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications to this unit not expressly approved by party responsible for compliance could void user's authority to operate this equipment.