


User's Manual
Magic Tap™ Model MT-90-xxx
(Touch-Control Dimmer - 4 brightness levels)

1. Install as show below. Be sure that your lamp switch is turned ON. Wait about 60 seconds when first installed.



2. Just **TAP** Magic Tap™ (near center) to adjust lamp brightness. (Use incandescent or halogen bulb only. Do not use MT-90-xxx with another dimmer in the same circuit.)

- 1st TAP = Dim
- 2nd TAP = Medium
- 3rd TAP = High
- 4th TAP = Off

3. To change Night Light brightness to Normal or Low, a slide switch is located on the bottom of Magic Tap™. Simply move the switch one way or the other.
4. It is normal for Magic Tap™ slightly warm to the touch during normal operation.

Warning: Do Not Use Near water!
Advertissement: N'employez pas près de l'Eau!
Advertencia: !No utilice Cerca del Agua!

Input Power: 110 VAC, 60 Hz Internal Dissipation: 5W
Maximum Load: 150W bulb CSA listed

Magic Tap™ is a registered trademark. All rights reserved.

For more information, call Customer Service 1-905-456-8883 or
email support@skylinkhome.com

Designed in US, assembled in China Rev 1 7 -1-2004