ASCENT X2 QUICK START GUIDE

Model 16-X2

Using a Third-Party Power Source (Optional)

IMPORTANT!

If you would like to use a third-party power source, such as solar, verify that it conforms to the following specs:

Input	12–24 VAC/DC **no more than 10% beyond this range**
Current Draw	less than 190 mA @ 12 VDC less than 160 mA @ 24 VDC

3a **Connect wires to unit as shown in Step 3.**

3b **Connect wires to your power source, making sure you connect positive to positive and negative to negative.**

CAUTION!

Double check that you've wired from positive on Ascent to positive on your power source and negative on Ascent to negative on your power source.

Reverse polarity can damage Ascent!

Installing a Third-Party SIM Card (Optional)

1 **Push existing SIM card in until it unlocks with "click" sound.**



2 **Remove existing SIM card and locate new SIM card.**



3 **Insert new SIM card until it locks in place with "click" sound.**



NEED HELP

Call **(844) 259-8265**
Email **support@summitcontrol.com**

We are available **Mon–Fri / 8am–5pm Central**

SECURITY BRANDS INC™
your *partner* in access control

© 2018 Security Brands, Inc. All rights reserved.