



Quick Guide

Indoor Pan & Tilt Camera

Model: WC-400PH



1. Package Contents



Indoor Pan & Tilt Camera
Model: WC-400PH



Power Adapter



Ethernet Cable



Mounting
Accessories

2. Connect the IP-Camera

NOTE: The Indoor Pan & Tilt Camera will only work with the SkylinkNet Internet Hub and the App. Please set up the Internet Hub and the SkylinkNet App first in order to connect the Indoor Pan & Tilt Camera. If you want setup the camera without the SkylinkNet Internet Hub, please contact Skylink Customer Service for instructions.


1. Screw antenna on the back of the camera.




2. Plug network cable into camera and into your router. (You can unplug this once WiFi is setup).
3. Plug power supply into camera and into an outlet.




3. Connect the IP-Camera




1. Open the SkylinkNet App and tap on "More" and "System Settings".



2. Tap on "Setup Wizard".




3. Tap on "Add Camera"



4. Tap on "Continue"

4. Setup the IP-Camera (Continued)



- 5. Enter a Name for Camera.
- 6. Enter the UID or Tap on "Scan Code" and scan the QR Code on the bottom of the camera or tap on "Search" and select the camera that is connected in the same router's network.
- 7. Enter the camera password.* The password is on the bottom of the camera.
- 8. Tap on "Preview"



9. Tap on "Save" if the status shows "Online".



10. Tap on "OK"

5. Setup Wifi




1. Tap on "Set up Wifi"




2. Select your Wifi Network.



3. Enter your wifi password and tap "OK".



4. Tap on "OK"




5. Tap on "Back"



6. Tap on "Go to Camera page"

6. Camera Screen Overview



- Live Video
- Online/Offline Status
- Full Screen
- Refresh
- Select Camera
- Mic ON/OFF
- Speaker ON/OFF
- Record Video
- Snapshot
- Folder Saved Videos and Snapshots

7. Warranty / Customer Service

This product is guaranteed to be free of defects in materials and workmanship for 1 year from the date of purchase. If this product is defective, call 1-800-304-1187 for repair or replacement parts. Guarantee does not include normal wear and tear or batteries.



If you have any questions, problems or missing parts, please call:

Skylink Customer Support

1-800-304-1187

9:00am – 5:00pm EST, Monday-Friday.

Or e-mail us at support@skylinkhome.com
www.skylinkhome.com

*Change the default password in the camera settings for security purpose.